
PERFECT WATER PRESSURE JUST WHEN YOU NEED IT

QUICK SELECTION GUIDE

FOR PRESSURE BOOSTING

PRESSURE BOOSTING - PUMP SELECTION

Use the table below to select the best Grundfos pump for any type of water supply task. Once you've settled on a pump model, use the corresponding sizing guide to get the perfect fit.




PRESSURE BOOSTING - PUMP SELECTION

Use the table below to select the best Grundfos pump for any type of water supply task. Once you've settled on a pump model, use the corresponding sizing guide to get the perfect fit.




PRESSURE BOOSTING - QUICK SIZING




Ex. sizing and selection

- 1. Required comfort level:
 - Adjustable contant pressure
- 2. Find the right booster:
 - How many taps: 6 taps
 - How many floors: 3 floors
- 3. Result: CMBE 1-44



ADJUSTABLE CONSTANT PRESSURE LEVEL





	Floors\Taps	1-5	6-10	11-20	21-50
	4	_	_	_	CMBE TWIN 5-62
	3	_	-	_	CMBE TWIN 5-62
	2	_	-	_	CMBE TWIN 5-62
\$	1	_	_	_	CMBE TWIN 5-31



Floors\ ^{Taps}	1-5	6-10	11-20
4	SCALA2 3-45*	_	_
3	SCALA2 3-45	SCALA2 3-45	-
€ 2	SCALA2 3-45	SCALA2 3-45	-
₡ 1	SCALA2 3-45	SCALA2 3-45	SCALA2 3-45

PRESSURE BOOSTING - QUICK SIZING

CONVENTIONAL PUMP CONTROL



SCALA1

- · All-in-one booster
- · Water on demand
- · Self-priming

Floors\ ^{Taps}	1-5	6-10	11-20	21-50
4	SCALA1 3-45*	SCALA1 5-55	_	-
3	SCALA1 3-45	SCALA1 3-45	SCALA1 5-55	-
€ 2	SCALA1 3-35	SCALA1 3-45	SCALA1 5-55	-
⊘ 1	SCALA13-25	SCALA1 3-35	SCALA1 3-45	_



SCALA1 TWIN (Duty/Assist)

- Easy solution for twin-booster
- · Easy installation
- · Enabled for Grundfos GO Remote

Floors\Taps	1-5	6-10	11-20	21-50
4	_	_	SCALA1 TWIN 5-55	SCALA1TWIN 5-55
3	-	_	_	SCALA1TWIN 5-55
₽ 2	_	_	_	SCALA1TWIN 5-55
₫ 1	_	_	_	SCALA1TWIN 5-55



Jet pump & booster

- · Easy to install
- · Self-priming
- · Robust design

	Taps or m³/h					
	1-5 taps 1-2 m³/h	6-10 taps 3-4 m³/h	11-20 taps 4-5 m³/h			
Manually controlled water supply	JP 3-42	JP 4-47/54	JP 5-48			
Contant water supply with pressure-drop compensation	JP 3-42 PT-V/H	JP 4-47/54 PT-V/H	JP 5-48 PT-V/H			
Constant water supply. Dry-running protection and anti-cycling function	JP 3-42 PM	JP 4-47/54 PM	JP 5-48 PM			



UPA

- · Low noise
- · High energy efficiency
- · Easy installation

Taps 1-2	Taps 2-4	Taps 4-8
UPA15-90	UPA15-120	UPA-15-160

PRESSURE BOOSTING - QUICK SIZING

CONVENTIONAL PUMP CONTROL



Grundfos SB pumps can be equipped with:

- full control (SBA)
- simple float switches for dry running protection
- or a connected priming kit with floating ball and strainer that collects the water right below the surface

See more details on variants on Grundfos Product Center

	Vertical Max. Hgeo [m] 1" pipe*		Horizontal Max. L [m] 1" pipe*	3/" ** / ½" *** pipe	Total hor. length [m] with 1" + ¾" / 1" + ½" pipes
	15		15	20/4	25/19
	15		10	22/5	32/15
SB(A) 3-45 at 3m ³ /h	10		15	33/8	48/23
2.8 bar	10		10	35/8.5	45/18.5
	5		15	46/11	61/26
	5		10	48/11.5	58/22.5
	15		15	9/2	16/17
	15		10	11/3	21/13
SB(A) 3-35	10		15	23/5.5	38/20.5
at 3m³/h 2.4 bar	10)	10	25/6	35/16
	5		15	36/8.5	51/23.5
	5		10	38/9	48/19
In					

^{*}Inner-ø 25mm

The calculation is based on the assumption that inside the home you use ½" for piping or ¾". From the cistern to the house and to that point where you change to a smaller diameter use 1". There are considered a NRV and gate valve, an extension from small to bigger pipe and a few 90° bends

^{**} Inner-ø 20mm


^{***} Inner-ø 15mm

GROUNDWATER - QUICK SIZING - PUMP

FLOW SIZING

		Kitchen sink	Dish washer, washing machine	Toilet w. wash basin and WC	Bathroom w. wash basin, WC and shower	Bathroom w. wash basin, WC and bathtub	Garden and lawn irrigation	Nominal flow [m³/h]	Recommended pump size
	Small house	1		1				1	SQ1
	Medium house	1	2	1	1			2	SQ2
SQ	Large house	2	2		1	1	2	3	SQ3
Compact designBuilt-in motor				2 x large house				5	SQ5
protection • Easy installation				3 x large house				7	SQ7

HEAD SIZING



Calculate max. pressure required

- 1. Pressure (H) at the tap requiring max. pressure = X
- 2. Static head (A + B + C) = Y
- 3. Pressure loss from friction in pipes and fittings = Z

$$H_{total} = X + Y + Z$$


Example of calculation

- 1. Pressure at the tap (max pressure): 3 bar = 30 m
- 2. Static head: 20 m + 5 m + 5 m = 30 m
- 3. Pressure loss from friction in pipes and fittings: 10 m+5 m = 15 m

Maximum pressure required:

$$H_{total} = 30 \text{ m} + 30 \text{ m} + 15 \text{ m} = 75 \text{ m}$$

PUMP SELECTION




GROUNDWATER - QUICK SIZING - CABLE

MAXIMUM CABLE LENGTH

	P2 [kW]	I _{max}		Wire cross secti	onal area [mm²]	
		[A]	1.5	2.5	4.0	6.0
				Maximum ca	ble length [m]	
	0.70	5.2	86	144	230	346
SQ CABLE • Supply voltage 240 V	1.15	8.4	53	89	142	214
· 5% voltage drop	ge drop 1.68	11.2	40	66	107	160
	1.85	12.0	37	62	100	150

HOW TO SELECT THE CROSS-SECTIONAL AREA



Supply voltage 240 V 5% voltage drop and cable supplied by Grundfos.

How to select the cross-sectional area of the individual wire of a submersible drop cable

- 1. Select SQ pump incl. motor size
- 2. Required total length of cable (D + E + F)
- 3. Read the cross-sectional area of individual wire of the drop cable

Example:

1. SQ pump incl. motor size

SQ 2-70, motor size 1.15 kW

2. Distance from pump to the power source (outside 44 m (D + F) + inside 6 m (E))

50 m

3. Selected cross-sectional area

1.5 mm²